

### Objective

Configure a digital DC drive to operate at two separate speeds using a Digital Input.


### Equipment

590 / 590+ DC drive and a computer with DSELite installed.

### Procedure

1. Launch DSELite on the computer.
2. Under **File|New**, open up the default configuration of the drive you have, (example: default8.590). Ensure that the name on the lower left corner matches the drive you are working on.
3. Using a free Digital Input, configure the template as shown below.
4. Set the desired Preset Speed as shown below.

24 VDC on Digital Input = Preset Speed  
 0 VDC on Digital Input = Analog Input reference.



If you have questions, please call the Product Support Group at (704) 588-3246.